

HOSE FITTING AL/NUT/SCREW CRIMP TYPE



PART NO.	Tube Size	Hose Size	
JAA-001	5/16	0 °	8
JAA-002	5/16	45 °	8
JAA-003	5/16	90 °	8
JCC-001	3/8(O)	0 °	8
JCC-002	3/8(O)	45 °	8
JCC-003	3/8(O)	90 °	8
JCC-019	3/8(F)	0 °	8
JCC-020	3/8(F)	45 °	8
JCC-021	3/8(F)	90 °	8
JDD-001	1/2(O)	0 °	10
JDD-002	1/2(O)	45 °	10
JDD-003	1/2(O)	90 °	10
JDD-019	1/2(F)	0 °	10
JDD-020	1/2(F)	45 °	10
JDD-021	1/2(F)	90 °	10
JFF-001	5/8(O)	0 °	12
JFF-002	5/8(O)	45 °	12
JFF-003	5/8(O)	90 °	12
JFF-019	5/8(F)	0 °	12
JFF-020	5/8(F)	45 °	12
JFF-021	5/8(F)	90 °	12

PART NO.	Tube Size	Hose Size	
JAA-010	5/16	0 °	8
JAA-011	5/16	45 °	8
JAA-012	5/16	90 °	8
JCC-010	3/8(O)	0 °	8
JCC-011	3/8(O)	45 °	8
JCC-012	3/8(O)	90 °	8
JCC-028	3/8(F)	0 °	8
JCC-029	3/8(F)	45 °	8
JCC-030	3/8(F)	90 °	8
JDD-010	1/2(O)	0 °	10
JDD-011	1/2(O)	45 °	10
JDD-012	1/2(O)	90 °	10
JDD-028	1/2(F)	0 °	10
JDD-029	1/2(F)	45 °	10
JDD-030	1/2(F)	90 °	10
JFF-010	5/8(O)	0 °	12
JFF-011	5/8(O)	45 °	12
JFF-012	5/8(O)	90 °	12
JFF-028	5/8(F)	0 °	12
JFF-029	5/8(F)	45 °	12
JFF-030	5/8(F)	90 °	12

HOSE FITTING AL/NUT CRIMP TYPE



PART NO.	Tube Size	Hose Size	Angle	Charge Valve
JAA-004	5/16	0"	8	With R12 Charge Valve
JAA-005	5/16	45"	8	With R12 Charge Valve
JAA-006	5/16	90"	8	With R12 Charge Valve

PART NO.	Tube Size	Hose Size	Angle	Charge Valve
JAA-007	5/16	0"	8	With R134a Charge Valve
JAA-008	5/16	45"	8	With R134a Charge Valve
JAA-009	5/16	90"	8	With R134a Charge Valve

JCC-004	3/8(O)	0"	8	With R12 Charge Valve
JCC-005	3/8(O)	45"	8	With R12 Charge Valve
JCC-006	3/8(O)	90"	8	With R12 Charge Valve
JCC-022	3/8(F)	0"	8	With R12 Charge Valve
JCC-023	3/8(F)	45"	8	With R12 Charge Valve
JCC-024	3/8(F)	90"	8	With R12 Charge Valve

JCC-007	3/8(O)	0"	8	With R134a Charge Valve
JCC-008	3/8(O)	45"	8	With R134a Charge Valve
JCC-009	3/8(O)	90"	8	With R134a Charge Valve
JCC-025	3/8(F)	0"	8	With R134a Charge Valve
JCC-026	3/8(F)	45"	8	With R134a Charge Valve
JCC-027	3/8(F)	90"	8	With R134a Charge Valve

JDD-004	1/2(O)	0"	10	With R12 Charge Valve
JDD-005	1/2(O)	45"	10	With R12 Charge Valve
JDD-006	1/2(O)	90"	10	With R12 Charge Valve
JDD-022	1/2(F)	0"	10	With R12 Charge Valve
JDD-023	1/2(F)	45"	10	With R12 Charge Valve
JDD-024	1/2(F)	90"	10	With R12 Charge Valve

JDD-007	1/2(O)	0"	10	With R134a Charge Valve
JDD-008	1/2(O)	45"	10	With R134a Charge Valve
JDD-009	1/2(O)	90"	10	With R134a Charge Valve
JDD-025	1/2(F)	0"	10	With R134a Charge Valve
JDD-026	1/2(F)	45"	10	With R134a Charge Valve
JDD-027	1/2(F)	90"	10	With R134a Charge Valve

JFF-004	5/8(O)	0"	12	With R12 Charge Valve
JFF-005	5/8(O)	45"	12	With R12 Charge Valve
JFF-006	5/8(O)	90"	12	With R12 Charge Valve
JFF-022	5/8(F)	0"	12	With R12 Charge Valve
JFF-023	5/8(F)	45"	12	With R12 Charge Valve
JFF-024	5/8(F)	90"	12	With R12 Charge Valve

JFF-007	5/8(O)	0"	12	With R134a Charge Valve
JFF-008	5/8(O)	45"	12	With R134a Charge Valve
JFF-009	5/8(O)	90"	12	With R134a Charge Valve
JFF-025	5/8(F)	0"	12	With R134a Charge Valve
JFF-026	5/8(F)	45"	12	With R134a Charge Valve
JFF-027	5/8(F)	90"	12	With R134a Charge Valve

HOSE FITTING AL/SCREW CRIMP TYPE



PART NO.	Tube Size	Hose Size		
JAA-013	5/16	0 °	8	With R12 Charge Valve
JAA-014	5/16	45 °	8	With R12 Charge Valve
JAA-015	5/16	90 °	8	With R12 Charge Valve
JCC-013	3/8(O)	0 °	8	With R12 Charge Valve
JCC-014	3/8(O)	45 °	8	With R12 Charge Valve
JCC-015	3/8(O)	90 °	8	With R12 Charge Valve
JCC-031	3/8(F)	0 °	8	With R12 Charge Valve
JCC-032	3/8(F)	45 °	8	With R12 Charge Valve
JCC-033	3/8(F)	90 °	8	With R12 Charge Valve
JDD-013	1/2(O)	0 °	10	With R12 Charge Valve
JDD-014	1/2(O)	45 °	10	With R12 Charge Valve
JDD-015	1/2(O)	90 °	10	With R12 Charge Valve
JDD-031	1/2(F)	0 °	10	With R12 Charge Valve
JDD-032	1/2(F)	45 °	10	With R12 Charge Valve
JDD-033	1/2(F)	90 °	10	With R12 Charge Valve
JFF-013	5/8(O)	0 °	12	With R12 Charge Valve
JFF-014	5/8(O)	45 °	12	With R12 Charge Valve
JFF-015	5/8(O)	90 °	12	With R12 Charge Valve
JFF-031	5/8(F)	0 °	12	With R12 Charge Valve
JFF-032	5/8(F)	45 °	12	With R12 Charge Valve
JFF-033	5/8(F)	90 °	12	With R12 Charge Valve

PART NO.	Tube Size	Hose Size		
JAA-016	5/16	0 °	8	With R134 Charge Valve
JAA-017	5/16	45 °	8	With R134 Charge Valve
JAA-018	5/16	90 °	8	With R134 Charge Valve
JCC-016	3/8(O)	0 °	8	With R134 Charge Valve
JCC-017	3/8(O)	45 °	8	With R134 Charge Valve
JCC-018	3/8(O)	90 °	8	With R134 Charge Valve
JCC-034	3/8(F)	0 °	8	With R134 Charge Valve
JCC-035	3/8(F)	45 °	8	With R134 Charge Valve
JCC-036	3/8(F)	90 °	8	With R134 Charge Valve
JDD-016	1/2(O)	0 °	10	With R134 Charge Valve
JDD-017	1/2(O)	45 °	10	With R134 Charge Valve
JDD-018	1/2(O)	90 °	10	With R134 Charge Valve
JDD-034	1/2(F)	0 °	10	With R134 Charge Valve
JDD-035	1/2(F)	45 °	10	With R134 Charge Valve
JDD-036	1/2(F)	90 °	10	With R134 Charge Valve
JFF-016	5/8(O)	0 °	12	With R134 Charge Valve
JFF-017	5/8(O)	45 °	12	With R134 Charge Valve
JFF-018	5/8(O)	90 °	12	With R134 Charge Valve
JFF-034	5/8(F)	0 °	12	With R134 Charge Valve
JFF-035	5/8(F)	45 °	12	With R134 Charge Valve
JFF-036	5/8(F)	90 °	12	With R134 Charge Valve

HOSE FITTING AL/NUT BARB TYPE



PART NO.	Tube Size	Hose Size
KAA-001	5/16 0°	8
KAA-002	5/16 45°	8
KAA-003	5/16 90°	8
KBE-001	3/11 0°	8
KBE-002	3/11 45°	8
KBE-003	3/11 90°	8




KCC-001	3/8(O) 0°	8
KCC-002	3/8(O) 45°	8
KCC-003	3/8(O) 90°	8
KCC-019	3/8(F) 0°	8
KCC-020	3/8(F) 45°	8
KCC-021	3/8(F) 90°	8



" O " RING FITTING

KDD-001	1/2(O) 0°	10
KDD-002	1/2(O) 45°	10
KDD-003	1/2(O) 90°	10
KDD-019	1/2(F) 0°	10
KDD-020	1/2(F) 45°	10
KDD-021	1/2(F) 90°	10



FLARE FITTING


KFF-001	5/8(O) 0°	12
KFF-002	5/8(O) 45°	12
KFF-003	5/8(O) 90°	12
KFF-019	5/8(F) 0°	12
KFF-020	5/8(F) 45°	12
KFF-021	5/8(F) 90°	12

HOSE FITTING AL/CRIMP TYPE



PART NO.	Tube Size	Hose Size	
JAZ-001	3/8	8	
JAZ-004	1/2	10	
JAZ-007	5/8	12	
JAZ-002	3/8	8	+ R12V
JAZ-005	1/2	10	+ R12V
JAZ-007	5/8	12	+ R12V
JAZ-003	3/8	8	+ R134aV
JAZ-006	1/2	10	+ R134aV
JAZ-009	5/8	12	+ R134aV

HOSE FITTING AL/CRIMP TYPE



BEADLOCK-SPLICER WITH R-12-134a SERVICE VALVE

PART NO	TUBE SIZE	HOSE SIZE	
JZZ-001	3/8	8	
JZZ-004	1/2	10	
JZZ-007	5/8	12	
JZZ-002	3/8	8	IN-LINE ACCESS VALVE R-12
JZZ-005	1/2	10	
JZZ-008	5/8	12	
JZZ-003	3/8	8	IN-LINE ACCESS VALVE R-134a
JZZ-006	1/2	10	
JZZ-009	5/8	12	

HOSE FITTING AL/BARB TYPE



PART NO.	Tube Size		Hose Size
KYY-001	3/8(9.5mm)	Straight Splicers	8
KYY-004	1/2(12mm)	Straight Splicers	10
KYY-007	5/8(14mm)	Straight Splicers	12
KYY-010	5/8(16mm)	Straight Splicers	15
KYY-013	(19mm)	Straight Splicers	
KYY-016	(23mm)	Straight Splicers	



PART NO.	Tube Size		Hose Size	NOTE
KYY-002	3/8(9.5mm)	Straight Splicers	8	With R-12 Valves
KYY-005	1/2(12mm)	Straight Splicers	10	With R-12 Valves
KYY-008	5/8(14mm)	Straight Splicers	12	With R-12 Valves
KYY-011	(16mm)	Straight Splicers	15	With R-12 Valves
KYY-014	(19mm)	Straight Splicers		With R-12 Valves
KYY-017	(23mm)	Straight Splicers		With R-12 Valves
KYY-003	3/8(9.5mm)	Straight Splicers	8	With R-134a Valves
KYY-006	1/2(12mm)	Straight Splicers	10	With R-134a Valves
KYY-009	5/8(14mm)	Straight Splicers	12	With R-134a Valves
KYY-012	(16mm)	Straight Splicers	15	With R-134a Valves
KYY-015	(19mm)	Straight Splicers		With R-134a Valves
KYY-018	(23mm)	Straight Splicers		With R-134a Valves



PART NO.	Tube Size		Hose Size
KZZ-001	3/8(9.5mm)	Tee Splicers	8
KZZ-002	1/2(12mm)	Tee Splicers	10
KZZ-003	5/8(14mm)	Tee Splicers	12

ALUMINUM PIPE



PART NO.	ITEM	SIZE			
AAA-001	AL/PIPE	5/16OXO (8mm)	0.5M	1	AAA-002-01
AAA-002	AL/PIPE	5/16OXO (8mm)	1.0M	1	AAA-007
AAA-003	AL/PIPE	5/16OXO (8mm)	1.5M	1	AAA-010
AAA-004	AL/PIPE	5/16OXO (8mm)	2.0M	1	AAA-011-01
AAA-005	AL/PIPE	5/16OXO (8mm)	2.5M	1	AAA-013-01
AAA-006	AL/PIPE	5/16OXO (8mm)	3.0M	1	AAA-015
AAA-007	AL/PIPE	3/8-OXO (9.5mm)	0.5M	1	AAA-047-01
AAA-008	AL/PIPE	3/8-OXO (9.5mm)	1.0M	1	AAA-052-01
AAA-009	AL/PIPE	3/8-OXO (9.5mm)	1.5M	1	AAA-055
AAA-010	AL/PIPE	3/8-OXO (9.5mm)	2.0M	1	AAA-056-01
AAA-011	AL/PIPE	3/8-OXO (9.5mm)	2.5M	1	AAA-058-01
AAA-012	AL/PIPE	3/8-OXO (9.5mm)	3.0M	1	AAA-060
AAA-013	AL/PIPE	3/8-FXF (9.5mm)	0.5M	1	AAA-032-01
AAA-014	AL/PIPE	3/8-FXF (9.5mm)	1.0M	1	AAA-037
AAA-015	AL/PIPE	3/8-FXF (9.5mm)	1.5M	1	AAA-040
AAA-016	AL/PIPE	3/8-FXF (9.5mm)	2.0M	1	AAA-041-01
AAA-017	AL/PIPE	3/8-FXF (9.5mm)	2.5M	1	AAA-043-01
AAA-018	AL/PIPE	3/8-FXF (9.5mm)	3.0M	1	AAA-045
AAB-001	AL/PIPE	5/16-OXO (8mm)	0.5M	1	AAB-002-01(NUT-SCREW)
AAB-002	AL/PIPE	5/16-OXO (8mm)	1.0M	1	AAB-007 (NUT-SCREW)
AAB-003	AL/PIPE	5/16-OXO (8mm)	1.5M	1	AAB-010 (NUT-SCREW)
AAB-004	AL/PIPE	5/16-OXO (8mm)	2.0M	1	AAB-011-01(NUT-SCREW)
AAB-005	AL/PIPE	5/16-OXO (8mm)	2.5M	1	AAB-013-01(NUT-SCREW)
AAB-006	AL/PIPE	5/16-OXO (8mm)	3.0M	1	AAB-015 (NUT-SCREW)
AAB-007	AL/PIPE	3/8-OXO (9.5mm)	0.5M	1	AAB-047-01(NUT-SCREW)
AAB-008	AL/PIPE	3/8-OXO (9.5mm)	1.0M	1	AAB-052-01(NUT-SCREW)
AAB-009	AL/PIPE	3/8-OXO (9.5mm)	1.5M	1	AAB-055 (NUT-SCREW)
AAB-010	AL/PIPE	3/8-OXO (9.5mm)	2.0M	1	AAB-056-01(NUT-SCREW)
AAB-011	AL/PIPE	3/8-OXO (9.5mm)	2.5M	1	AAB-058-01(NUT-SCREW)
AAB-012	AL/PIPE	3/8-OXO (9.5mm)	3.0M	1	AAB-060 (NUT-SCREW)
AAB-013	AL/PIPE	3/8-FXF (9.5mm)	0.5M	1	AAB-032-01(NUT-SCREW)
AAB-014	AL/PIPE	3/8-FXF (9.5mm)	1.0M	1	AAB-037 (NUT-SCREW)
AAB-015	AL/PIPE	3/8-FXF (9.5mm)	1.5M	1	AAB-040 (NUT-SCREW)
AAB-016	AL/PIPE	3/8-FXF (9.5mm)	2.0M	1	AAB-041-01(NUT-SCREW)
AAB-017	AL/PIPE	3/8-FXF (9.5mm)	2.5M	1	AAB-043-01(NUT-SCREW)
AAB-018	AL/PIPE	3/8-FXF (9.5mm)	3.0M	1	AAB-045 (NUT-SCREW)



BEADLOCK O-Ring MALE



PART NO.	Tube	Hose Size	NOTE	PART NO.	Tube	Hose Size	NOTE
JCA-001	3/8-0 °	8		JCA-007	3/8-0 °	8	With R134 Charge Valve
JCA-002	3/8-45 °	8		JCA-008	3/8-45 °	8	With R134 Charge Valve
JCA-003	3/8-90 °	8		JCA-009	3/8-90 °	8	With R134 Charge Valve
JDA-001	1/2-0 °	10		JDA-007	1/2-0 °	10	With R134 Charge Valve
JDA-002	1/2-45 °	10		JDA-008	1/2-45 °	10	With R134 Charge Valve
JDA-003	1/2-90 °	10		JDA-009	1/2-90 °	10	With R134 Charge Valve
JFA-001	5/8-0 °	12		JFA-007	5/8-0 °	12	With R134 Charge Valve
JFA-002	5/8-45 °	12		JFA-008	5/8-45 °	12	With R134 Charge Valve
JFA-003	5/8-90 °	12		JFA-009	5/8-90 °	12	With R134 Charge Valve
JCA-004	3/8-0 °	8	With R12 Charge Valve				
JCA-005	3/8-45 °	8	With R12 Charge Valve				
JCA-006	3/8-90 °	8	With R12 Charge Valve				
JDA-004	1/2-0 °	10	With R12 Charge Valve				
JDA-005	1/2-45 °	10	With R12 Charge Valve				
JDA-006	1/2-90 °	10	With R12 Charge Valve				
JFA-004	5/8-0 °	12	With R12 Charge Valve				
JFA-005	5/8-45 °	12	With R12 Charge Valve				
JFA-006	5/8-90 °	12	With R12 Charge Valve				

BEADLOCK O-Ring MALE



PART NO.	Tube	Hose Size	NOTE	PART NO.	Tube	Hose Size	NOTE
KCA-001	3/8-0 °	8		KCA-007	3/8-0 °	8	With R134 Charge Valve
KCA-002	3/8-45 °	8		KCA-008	3/8-4 °	8	With R134 Charge Valve
KCA-003	3/8-90 °	8		KCA-009	3/8-90 °	8	With R134 Charge Valve
KDA-001	1/2-0 °	10		KDA-007	1/2-0 °	10	With R134 Charge Valve
KDA-002	1/2-45 °	10		KDA-008	1/2-45 °	10	With R134 Charge Valve
KDA-003	1/2-90 °	10		KDA-009	1/2-90 °	10	With R134 Charge Valve
KFA-001	5/8-0 °	12		KFA-007	5/8-0 °	12	With R134 Charge Valve
KFA-002	5/8-45 °	12		KFA-008	5/8-45 °	12	With R134 Charge Valve
KFA-003	5/8-90 °	12		KFA-009	5/8-90 °	12	With R134 Charge Valve
KCA-004	3/8-0 °	8	With R12 Charge Valve				
KCA-005	3/8-45 °	8	With R12 Charge Valve				
KCA-006	3/8-90 °	8	With R12 Charge Valve				
KDA-004	1/2-0 °	10	With R12 Charge Valve				
KDA-005	1/2-45 °	10	With R12 Charge Valve				
KDA-006	1/2-90 °	10	With R12 Charge Valve				
KFA-004	5/8-0 °	12	With R12 Charge Valve				
KFA-005	5/8-45 °	12	With R12 Charge Valve				
KFA-006	5/8-90 °	12	With R12 Charge Valve				

HOSE FITTING/H(MODEL)AL NUT CRIMP TYPE



PART NO.	Tube Size	Hose Size	NOTE	PART NO.	Tube Size	Hose Size	NOTE
JHA-001	3/8-0 °	8		JHC-004	5/8-0 ° (14mm)	12	With R12 Charge Valve
JHA-002	3/8-45 °	8		JHC-005	5/8-45 ° (14mm)	12	With R12 Charge Valve
JHA-003	3/8-90 °	8		JHC-006	5/8-90 ° (14mm)	12	With R12 Charge Valve
JHB-001	1/2-0 °	10		JHD-004	5/8-0 ° (16mm)	15	With R12 Charge Valve
JHB-002	1/2-45 °	10		JHD-005	5/8-45 ° (16mm)	15	With R12 Charge Valve
JHB-003	1/2-90 °	10		JHD-006	5/8-90 ° (16mm)	15	With R12 Charge Valve
JHC-001	5/8-0 ° (14mm)	12		JHA-007	3/8-0 °	8	With R134 Charge Valve
JHC-002	5/8-45 ° (14mm)	12		JHA-008	3/8-45 °	8	With R134 Charge Valve
JHC-003	5/8-90 ° (14mm)	12		JHA-009	3/8-90 °	8	With R134 Charge Valve
JHD-001	5/8-0 ° (16mm)	15		JHB-007	1/2-0 °	10	With R134 Charge Valve
JHD-002	5/8-45 ° (16mm)	15		JHB-008	1/2-45 °	10	With R134 Charge Valve
JHD-003	5/8-90 ° (16mm)	15		JHB-009	1/2-90 °	10	With R134 Charge Valve
JHA-004	3/8-0 °	8	With R12 Charge Valve	JHC-007	5/8-0 ° (14mm)	12	With R134 Charge Valve
JHA-005	3/8-45 °	8	With R12 Charge Valve	JHC-008	5/8-45 ° (14mm)	12	With R134 Charge Valve
JHA-006	3/8-90 °	8	With R12 Charge Valve	JHC-009	5/8-90 ° (14mm)	12	With R134 Charge Valve
JHB-004	1/2-0 °	10	With R12 Charge Valve	JHD-007	5/8-0 ° (16mm)	15	With R134 Charge Valve
JHB-005	1/2-45 °	10	With R12 Charge Valve	JHD-008	5/8-45 ° (16mm)	15	With R134 Charge Valve
JHB-006	1/2-90 °	10	With R12 Charge Valve	JHD-009	5/8-90 ° (16mm)	15	With R134 Charge Valve

HOSE FITTING/H(MODEL)AL SCREW CRIMP TYPE



PART NO.	Tube Size	Hose Size	NOTE	PART NO.	Tube Size	Hose Size	NOTE
JHA-010	3/8-0 °	8		JHC-013	5/8-0 ° (14mm)	12	With R12 Charge Valve
JHA-011	3/8-45 °	8		JHC-014	5/8-45 ° (14mm)	12	With R12 Charge Valve
JHA-012	3/8-90 °	8		JHC-015	5/8-90 ° (14mm)	12	With R12 Charge Valve
JHB-010	1/2-0 °	10		JHD-013	5/8-0 ° (16mm)	15	With R12 Charge Valve
JHB-011	1/2-45 °	10		JHD-014	5/8-45 ° (16mm)	15	With R12 Charge Valve
JHB-012	1/2-90 °	10		JHD-015	5/8-90 ° (16mm)	15	With R12 Charge Valve
JHC-010	5/8-0 ° (14mm)	12		JHA-016	3/8-0 °	8	With R134 Charge Valve
JHC-011	5/8-45 ° (14mm)	12		JHA-017	3/8-45 °	8	With R134 Charge Valve
JHC-012	5/8-90 ° (14mm)	12		JHA-018	3/8-90 °	8	With R134 Charge Valve
JHD-010	5/8-0 ° (16mm)	15		JHB-016	1/2-0 °	10	With R134 Charge Valve
JHD-011	5/8-45 ° (16mm)	15		JHB-017	1/2-45 °	10	With R134 Charge Valve
JHD-012	5/8-90 ° (16mm)	15		JHB-018	1/2-90 °	10	With R134 Charge Valve
JHA-013	3/8-0 °	8	With R12 Charge Valve	JHC-016	5/8-0 ° (14mm)	12	With R134 Charge Valve
JHA-014	3/8-45 °	8	With R12 Charge Valve	JHC-017	5/8-45 ° (14mm)	12	With R134 Charge Valve
JHA-015	3/8-90 °	8	With R12 Charge Valve	JHC-018	5/8-90 ° (14mm)	12	With R134 Charge Valve
JHB-013	1/2-0 °	10	With R12 Charge Valve	JHD-016	5/8-0 ° (16mm)	15	With R134 Charge Valve
JHB-014	1/2-45 °	10	With R12 Charge Valve	JHD-017	5/8-45 ° (16mm)	15	With R134 Charge Valve
JHB-015	1/2-90 °	10	With R12 Charge Valve	JHD-018	5/8-90 ° (16mm)	15	With R134 Charge Valve

HOSE FITTING/H(MODEL)AL NUT BARB TYPE



PART NO.	Tube Size	Hose Size	NOTE	PART NO.	Tube Size	Hose Size	NOTE
KHA-001	3/8-0 °	8		KHC-004	5/8-0 ° (14mm)	12	With R12 Charge Valve
KHA-002	3/8-45 °	8		KHC-005	5/8-45 ° (14mm)	12	With R12 Charge Valve
KHA-003	3/8-90 °	8		KHC-006	5/8-90 ° (14mm)	12	With R12 Charge Valve
KHB-001	1/2-0 °	10		KHD-004	5/8-0 ° (16mm)	15	With R12 Charge Valve
KHB-002	1/2-45 °	10		KHD-005	5/8-45 ° (16mm)	15	With R12 Charge Valve
KHB-003	1/2-90 °	10		KHD-006	5/8-90 ° (16mm)	15	With R12 Charge Valve
KHC-001	5/8-0 ° (14mm)	12		KHA-007	3/8-0 °	8	With R134 Charge Valve
KHC-002	5/8-45 ° (14mm)	12		KHA-008	3/8-45 °	8	With R134 Charge Valve
KHC-003	5/8-90 ° (14mm)	12		KHA-009	3/8-90 °	8	With R134 Charge Valve
KHD-001	5/8-0 ° (16mm)	15		KHB-007	1/2-0 °	10	With R134 Charge Valve
KHD-002	5/8-45 ° (16mm)	15		KHB-008	1/2-45 °	10	With R134 Charge Valve
KHD-003	5/8-90 ° (16mm)	15		KHB-009	1/2-90 °	10	With R134 Charge Valve
KHA-004	3/8-0 °	8	With R12 Charge Valve	KHC-007	5/8-0 ° (14mm)	12	With R134 Charge Valve
KHA-005	3/8-45 °	8	With R12 Charge Valve	KHC-008	5/8-45 ° (14mm)	12	With R134 Charge Valve
KHA-006	3/8-90 °	8	With R12 Charge Valve	KHC-009	5/8-90 ° (14mm)	12	With R134 Charge Valve
KHE-004	1/2-0 °	10	With R12 Charge Valve	KHD-007	5/8-0 ° (16mm)	15	With R134 Charge Valve
KHE-005	1/2-45 °	10	With R12 Charge Valve	KHD-008	5/8-45 ° (16mm)	15	With R134 Charge Valve
KHE-006	1/2-90 °	10	With R12 Charge Valve	KHD-009	5/8-90 ° (16mm)	15	With R134 Charge Valve

HOSE FITTING/H(MODEL)AL SCREW BARB TYPE



PART NO.	Tube Size	Hose Size	NOTE	PART NO.	Tube Size	Hose Size	NOTE
KHA-010	3/8-0 °	8		KHC-013	5/8-0 ° (14mm)	12	With R12 Charge Valve
KHA-011	3/8-45 °	8		KHC-014	5/8-45 ° (14mm)	12	With R12 Charge Valve
KHA-012	3/8-90 °	8		KHC-015	5/8-90 ° (14mm)	12	With R12 Charge Valve
KHB-010	1/2-0 °	10		KHD-013	5/8-0 ° (16mm)	15	With R12 Charge Valve
KHB-011	1/2-45 °	10		KHD-014	5/8-45 ° (16mm)	15	With R12 Charge Valve
KHB-012	1/2-90 °	10		KHD-015	5/8-90 ° (16mm)	15	With R12 Charge Valve
KHC-010	5/8-0 ° (14mm)	12		KHA-016	3/8-0 °	8	With R134 Charge Valve
KHC-011	5/8-45 ° (14mm)	12		KHA-017	3/8-45 °	8	With R134 Charge Valve
KHC-012	5/8-90 ° (14mm)	12		KHA-018	3/8-90 °	8	With R134 Charge Valve
KHD-010	5/8-0 ° (16mm)	15		KHB-016	1/2-0 °	10	With R134 Charge Valve
KHD-011	5/8-45 ° (16mm)	15		KHB-017	1/2-45 °	10	With R134 Charge Valve
KHD-012	5/8-90 ° (16mm)	15		KHB-018	1/2-90 °	10	With R134 Charge Valve
KHA-013	3/8-0 °	8	With R12 Charge Valve	KHC-016	5/8-0 ° (14mm)	12	With R134 Charge Valve
KHA-014	3/8-45 °	8	With R12 Charge Valve	KHC-017	5/8-45 ° (14mm)	12	With R134 Charge Valve
KHA-015	3/8-90 °	8	With R12 Charge Valve	KHC-018	5/8-90 ° (14mm)	12	With R134 Charge Valve
KHB-013	1/2-0 °	10	With R12 Charge Valve	KHD-016	5/8-0 ° (16mm)	15	With R134 Charge Valve
KHB-014	1/2-45 °	10	With R12 Charge Valve	KHD-017	5/8-45 ° (16mm)	15	With R134 Charge Valve
KHB-015	1/2-90 °	10	With R12 Charge Valve	KHD-018	5/8-90 ° (16mm)	15	With R134 Charge Valve

FREON HOSE



PRODUCT NO.	ITEM SIZE	UNIT	
DAA-001	FREON HOSE: 3/8(8mm)	100M	R-12/R Only Use
EAA-001	FREON HOSE: 1/2(10mm)	100M	R-12/R Only Use
FAA-001	FREON HOSE: 5/8(12mm)	100M	R-12/R Only Use
DBB-001	FREON HOSE: 3/8(8mm)	100M	R-134a Only Use
EBB-001	FREON HOSE: 1/2(10mm)	100M	R-134a Only Use
FBB-001	FREON HOSE: 5/8(12mm)	100M	R-134a Only Use

ALUMINUM SOCKET



PRODUCT NO.	ITEM	SIZE	NOTE
IAA-002	AL-SOCKET 3/8	(22X30-8.7)	Aluminium Socket
IAA-006	AL-SOCKET 1/2	(27X33-11.5)	Aluminium Socket
IAA-007	AL-SOCKET 5/8	(27X33-13.5)	Aluminium Socket
IAA-011	AL-SOCKET 5/8	(29X33-16.5)	Aluminium Socket
	AL-SOCKET 5/8	(34X43-19.8)	Aluminium Socket

EXPANSION VALVE FOR CAR COOLERS



AF-3040 BF-3040



AR-3040 BR-3040



AR-2540 BR-2540



AR-1622 BR-1622



AR-1620 BR-1620

SPECIFICATIONS

TYPE	Capacities (U.S.Ton)	Connections (Inlet * Outlet)	Equalizer terminal	Heat Resistance	Working Proof	Pressure Proof	Superheat	Weight
BF-3040	1.0T	Flare * Flare 9.52*12.7(mm) 3/8*1/2(inch)	Internal	G-charge 120°C 250°F A-charge L-charge 80°C 175°F	High Pressure Side 30kg/cm ² G	40 kg/cm ² G	0.5-7deg	140gr
AF-3040	1.5T							
BR-2540	1.0T	Oring * Oring In 9/16-18UNF Out 3/4-16UNF						
AR-2540	1.5T							
BR-3040	1.0T	Oring * Oring In 5/8-18UNF Out 3/4-16UNF						
AR-3040	1.5T							
BR-1620	1.0T	Oring * Oring In M10*P1.5 Out M20*P1.5						
AR-1620	1.5T							
BR-1622	1.0T	Oring * Oring In M10*P1.5 Out M22*P1.5						
AR-1622	1.5T							